




**Steering wheel remote control operation
of ZE-NC3810 in compatible FORD cars.**



- | | |
|--|---|
| <p>1 VOL + : Volume up</p> <p>2 VOL - : Volume down</p> <p>3 VOICE : Pick up/Hang up call.
Short press >
change to Bluetooth mode
Bluetoothmode >
Activate voice tag control
(Voicetag present)</p> | <p>4 MODE : Choose playback mode</p> <p>5 SEEK ^: Short press > Previous song
Long press > Rewind</p> <p>6 SEEK v: Short press > Next song
Long press > Fast forward</p> |
|--|---|

**Steering wheel remote control operation
of ZE-NC3810 in compatible FORD cars.**



- | | | | |
|------------------|---|------------------|--|
| 1 VOL + : | Volume up | 4 MODE : | Choose playback mode |
| 2 VOL - : | Volume down | 5 SEEK ^: | Short press > Previous song
Long press > Rewind |
| 3 VOICE : | Pick up/Hang up call.
Short press >
change to Bluetooth mode
Bluetoothmode >
Activate voice tag control
(Voicetag present) | 6 SEEK v: | Short press > Next song
Long press > Fast forward |
| | | 7 ANSW. : | Pick up call |
| | | 8 END : | Hang up call |